Computer Networks


Lab 05

Hamza Shahid 20P-0117 BSSE-5A


Task 01:

Steps:

• First make this protocol by drag and drop.



• Then setup the DHCP server.



Router(config-if)#interface Fa1/0

Router(config-if)#ip address 192.168.2.1 255.255.255.0

Router(config-if)#no shutdown


Router(config-if)#interface Fa0/0

Router(config-if)#ip address 192.168.1.1 255.255.255.0


Router(config-if)#no shutdown


Router(config-if)#interface Fa1/0

Router(config-if)#ip helper-address 192.168.1.2



 Then turn all the PCs to the DHCP. And the IP will be assigned automatically.







Task 02:

Steps:

First make this protocol by drag and drop as we did in Lab#04.



- Then add Flex and Slate as servers in protocol and assign IP addresses to them.
- Now if you go to to PC and access the slate or flex by their IP, you can see the changes you did in their index files.





(a):

When we access it with the IP, it directly access the IP without sending request to DNS server.

(b):

When we access it with the URL, it sends request to DNS server and then access the desired server.